

Limited transport dimensions often require the use of assembly joints for large structures. Or column loads should be transferred through beams without deformations. This pin and socket system makes it easy to assemble high-strength connections.



[more infos](#)