

Bracings in walls & roof surfaces serve to spatially stabilize the load-bearing components. In most cases, the columns and beams achieve their maximum load-bearing capacity only thanks to these constructions. Our bracings provide the necessary rigidity and load-bearing capacity and are easy to install. With the “plug-in brace”, only two bolts are required for assembly and the WV rod assumes its stabilizing function.



[more infos](#)